

## Screwdrivers - Clutch type: SLIP-TRK/RE

STRAIGHT SCREWDRIVERS - Lever start - ERGOVIT series

WATT: 220

Hexagonal coupling: 1/4"

Data sheet  
**ERGOVIT22DRE**



### Description

Slip clutch. Adjusting this type of clutch is easy; just turn the ring nut on the outside. This type is ideal where frequent changes of tightening torque within the spring range are required and where you need to maintain a high degree of precision.

### Technical specification

|                          |              |
|--------------------------|--------------|
| Model                    | ERGOVIT22DRE |
| Code                     | 8301218      |
| No-load speed - rpm/min  | 1900         |
| Screw tightening - Metal | 6            |
| Screw tightening - Wood  | 4x40         |
| Torque - Nm              | 3            |
| Spring colour - *        | Yellow       |
| Length - mm              | 270          |
| Body - ø mm              | 38           |
| Air connection           | 1/4"GAS      |
| Weight - Kg              | 0,95         |
| Hose - ø min mm          | 8            |
| Air consumption - NI/min | 430          |

## Screwdrivers - Clutch type: SLIP-TRK/RE

STRAIGHT SCREWDRIVERS - Lever start - ERGOVIT series

WATT: 220

Hexagonal coupling: 1/4"

Data sheet  
**ERGOVIT22DRE**

### Overall dimensions

